

100%
AUSTRALIAN
OWNED COMPANY

ATLANTIC WINCHES



Perfect choice
for marine
and general
purpose

Engineering
tested by NATA
accredited
laboratory

Dacromet™
rust resistant
finish to all
winches

Size doesn't matter.

CADET WINCH SERIES

The Atlantic range of Cadet Winches are available in two different ratio sizes – 3:1 or 4:1 with load capacity ratings operating from 300 to 550kg and are available with cable,

webbing strap or no cable options. These entry level winches are perfect for those looking for a budget winch that can really perform.



Atlantic Cadet Winch 300kg series

ATLANTIC
W I N C H E S



PRODUCT CODES	CMW000C	CMW001NC	CMW002W
GEAR RATIO	3:1	3:1	3:1
CABLE/WEBBING/ROPE TYPE	Cable	-	Webbing
HOOK TYPE	S Hook	-	S Hook
APPLICATION	Boat Trailer	Boat Trailer	Boat Trailer
CABLE/WEBBING/ROPE LENGTH	6m x 4mm	-	4.5m
DIRECT LIFT CAPACITY	300kg	300kg	300kg
UNIT WEIGHT	2.4kg	2.4kg	2.4kg
RATCHET TYPE	Lever Action	Lever Action	Lever Action
DRUM HUB	30mm	30mm	30mm
FLANGE DIAMETER	103mm	103mm	103mm
DRUM WIDTH (ID)	51mm	51mm	51mm
CABLE/WEBBING/ROPE MAXIMUM LOAD	1142kg	-	1795kg
CABLE/WEBBING/ROPE MAXIMUM STRESS	11.2kN	-	17.6kN
BARCODE NUMBER	9 334751 000893	9 334751 000916	9 337451 000862

- ✓ 3:1 GEAR RATIO
- ✓ CABLE OR WEBBING
- ✓ S HOOK
- ✓ 300KG CAPACITY
- ✓ ECONOMY SERIES
- ✓ DACROMET FINISH

Atlantic Cadet Winch 550kg series



PRODUCT CODES	CMW003C	CMW004NC	CMW005W	CMW006W
GEAR RATIO	4:1	4:1	4:1	4:1
CABLE/WEBBING/ROPE TYPE	Cable	-	Webbing	Webbing
HOOK TYPE	S Hook	-	S Hook	Snap Hook
APPLICATION	Boat Trailer	Boat Trailer	Boat Trailer	Boat Trailer
CABLE/WEBBING/ROPE LENGTH	6m x 4mm	-	6m	6m
DIRECT LIFT CAPACITY	550kg	550kg	550kg	550kg
UNIT WEIGHT	3.0kg	3.0kg	3.0kg	3.0kg
RATCHET TYPE	Lever Action	Lever Action	Lever Action	Lever Action
DRUM HUB	50mm	50mm	50mm	50mm
FLANGE DIAMETER	133mm	133mm	133mm	133mm
DRUM WIDTH (ID)	51mm	51mm	51mm	51mm
CABLE/WEBBING/ROPE MAXIMUM LOAD	1142kg	-	1142kg	1142kg
CABLE/WEBBING/ROPE MAXIMUM STRESS	11.2kN	-	11.2kN	11.2kN
BARCODE NUMBER	9 334751 000909	9 334751 000923	9 334751 000879	9 334751 000930

- ✓ 4:1 GEAR RATIO
- ✓ CABLE OR WEBBING
- ✓ S OR SNAP HOOKS
- ✓ 550KG CAPACITY
- ✓ ECONOMY SERIES
- ✓ DACROMET FINISH

100%
AUSTRALIAN
OWNED COMPANY

ATLANTIC WINCHES

MARINE WINCH OPERATION GUIDE

- Keep your hands clear of the webbing or cable and its opening during operation and/or when spooling.
- Keep your clothing clear of the webbing or cable and its opening during operation and/or when spooling.
- Our winches are not intended to lift, lower or transfer people at any time.
- Alert all people in close proximity before use of the winch.
- Keep non-operating users away from the working area of the winch.
- Do not use any Atlantic Marine Winches for lifting applications. Refer to the range of Atlantic Brake Winches range.
- Never pull (vertically lift) more than the capacity stated on the winch.
- Ensure cables or webbing are secured correctly before use of the winch.
- Never apply a load on the winch with the cable or webbing in full extension. Ensure at least 3 full wraps of cable or webbing are on the drum at all times.
- Regularly examine all parts of the winch and do not use if damaged. Repair or replace any defective parts of the winch.
- Never disengage the clutch while the cable or webbing is under tension.
- Never engage the clutch while the drum is rotating.
- Never winch when there are less than 3 wraps of cable or webbing on the drum at all times.
- Winch out slowly and steadily. Be sure that the cable or webbing is winding evenly and tightly around the drum at all times.
- Never use a Marine Winch to tow another vehicle or used as a load securing device ie. (boat on a trailer).

BRAKE WINCH OPERATION GUIDE

- Keep your hands clear of the cable, hook and its opening during operation and/or when spooling.
- Keep your clothing clear of the cable, hook and its opening during operation and/or when spooling.
- Tighten the brake winch handle adapter before use to ensure optimal braking ability.
- Do not lift people or lift a load over people. Alert all people in close proximity and keep non-operating users away from the working area before use of the brake winch.
- Never lift more than the capacity stated on the brake winch.
- Ensure cable is secured correctly before use of the brake winch.
- Never apply a load on the brake winch with the cable in full extension.
- Ensure at least 3 full wraps of cable are on the drum at all times.
- Regularly examine all parts of the brake winch and do not use if damaged. Repair or replace any defective parts of the brake winch.
- Never lubricate (grease) the braking mechanism of the brake winch.
- Never disengage the clutch while the cable is under tension.
- Never engage the clutch while the drum is rotating.
- Never winch when there are less than 3 wraps of cable on the drum at all times.
- Never wrap the cable around a load as this will damage the cable.
- Do not swing the load as this may cause damage.
- Never leave a suspended load unattended.



It is the operators responsibility to determine the suitability of the equipment to its intended use. Check all applicable codes, caution and warning notations on the product.